INSTRUCTIONS

CURRENT INFORMATION LETTER
INSPECTION AND LUBRICATION SCHEDULE
EXPORT DIESEL ELECTRIC LOCOMOTIVES POWERED WITH GE ENGINES

The following changes in maintenance schedule are recommended:

Page 10 — SIX MONTHS, Delete:

Item	Tab Ref.	Inspection and Maintenance
Low Pressure Fuel Hose	DE-14	Inspect and replace, if required.

Page 13 — ONE YEAR, Add:

Item	Tab Ref.	Inspection and Maintenance
Low Pressure Fuel Hose	DE-14	Inspect and replace, if necessary.

Page 15 — FOUR YEARS, Add:

Item	Tab Ref.	Inspection and Maintenance
Low Pressure Fuel Hose	DE-14	Replace.

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

Verify numbers for parts, tools, or material by using the Renewal Parts or Tool Catalogs, or contact your General Electric representative for assistance. Do not order from this publication.

RM-2
10-81 (1000) RER

GENERAL ELECTRIC

PRINTED IN U.S.A.
E